
OPENING THE DOORS & SETTING UP THE RAMPS



OPENING THE DOOR & SETTING UP THE RAMPS



[1]



[2]



[3]



[4]



[5]



[6] Remove ramp locking pins.



[7] Pull out ramp.



[8]



[9]



[10] Locate ramp on rear door step rail.



[11] Replace locking pins.



[12] Ramp ready to use.

OPENING THE DOOR & SETTING UP THE RAMPS



[13] Door can be closed with the ramp left in place.



[14]



[15]